



Towbar Rock Deflector

T-R-D

You only install 6 eye bolts to hold this rock deflector securely to both vehicles. Four eye bolts are mounted to the underside of the motorhome bumper and 2 on the tow vehicle the same way. The black stretchy material has a quick disconnect for each eye bolt connect them and then use the pole across the towbar to hold it up off the ground. This is a simple yet very effective way of keeping all the debris from chipping the paint off your tow vehicle.

Hooking up and unhooking just takes a few minutes.



This all folds down and will stow in a protective bag that is provided.



N.S.A. RV Products Inc.
445 W. Lincoln Rd.
Iola, KS 66749
800-933-3372